



FLEX24 Switch User Guide

Version 7.1.0



Proprietary Notice

Copyright © 2018 NVT Phybridge Inc. All rights reserved.

All information contained in this document is confidential and proprietary to NVT Phybridge Inc. Any disclosure, duplication, reproduction or transmission of this document or the information it contains is prohibited without the prior written authorization of NVT Phybridge Inc. NVT Phybridge believes that at the time of publication, this document accurately reflects FLEX switch features, requirements and specifications. However, this document may contain errors or omissions, and NVT Phybridge makes no warranties regarding the content of this document. NVT Phybridge is not responsible for any loss or damages arising from the use or misuse of this document. The information contained in this document as well as all product specifications are subject to change without notice.

Trademarks

NVT Phybridge is a trademark of NVT Phybridge Inc.

All other trademarks, registered trademarks and service marks are the property of their respective owners.

NVT Phybridge Inc. Corporate Headquarters

3457 Superior Court

Unit 3

Oakville, ON

L6L 0C4, Canada

www.nvtphybridge.com

NVT Phybridge FLEX Switch Hardware Installation Guide

Release 7.1.0 – 2018

®,™ Trademark of NVT Phybridge Inc.

© Copyright 2018, NVT Phybridge Inc.

All rights reserved

Warranty Information

All statements in this document concerning the NVT Phybridge FLEX switch are for informational purposes only. No part of this document constitutes a warranty, either express or implied, regarding the FLEX switch. Our standard limited warranty is provided with the sales contract and/or product package.

Service and Support

NVT Phybridge is dedicated to customer satisfaction and the high quality of its products. Our technical support team is prepared to assist you in maximizing the efficiency and dependability of your FLEX switch environment and will provide you with an immediate solution should a problem with your product arise. Contact us to discuss a plan of action.

Returning a FLEX Switch

If you must return a FLEX switch, FLEX adapter, or accessory component to NVT Phybridge Inc., ensure that all items are adequately protected with insulating material and packaged in the original carton before shipping. Failure to do so may void the equipment warranty. Consult the warranty statements included with the sales contract and/or product package. Contact us for specific RMA requirements before you ship.

Audience

This document is intended for the use of service technicians, system administrators, information technology experts and other personnel who are qualified to install, configure and maintain the FLEX switch in the IP network environment. The tasks and procedures described in this guide require a basic understanding of IP communications, Ethernet LAN networks and the strategies and solutions currently practiced in your network environment. This document assumes that you are familiar with the architecture, specifications and functionality of your network. NVT Phybridge Communications Director (MCD) certification training is required.

Document Conventions

In this document, some instructions are given particular emphasis to denote cautions, warnings and notes.

Cautions

A caution contains an instruction that the reader *must* follow in order to **prevent damage to equipment, network failure or loss of data**.

Example:



CAUTION: Do not expose the FLEX switch or any of its components to a magnetic field or electrostatic charge. Damage to system components could result.

Warnings

A warning contains an instruction that the reader *must* follow in order to **prevent electrical shock, death or serious injury to personnel**.

Example:



WARNING: Ensure that the FLEX switch is independently grounded with a wire securely attached to the ground lug at the rear of the switch.

Notes or Tips

A note or tip provides helpful information related to the topic of discussion.

Examples:



Note: The power supply unit is a field-replaceable part.



Tip: Use the handle on the right side to pull the power supply unit out.

Contents

1. Overview	1
About this Guide	1
About the Admin GUI	1
Software Version	2
Logging into the Switch	2
Managing Multiple Switches	2
2. System Page	3
About the System Page	3
System > Overview	3
System Overview	4
Ethernet Port Status	5
Viewing port status	6
Controlling power to downlink ports	6
System > Performance	7
CPU Load.....	8
Memory (Megabytes)	8
Power (Watts).....	9
Temperature (Celsius)	10
System> Log	11
Selecting the number of events to display	11
Searching Log entries	11
Adding markers to the log.....	12
Downloading the log file.....	12
3. Ethernet Page.....	13
About the Ethernet Page	13
Ethernet > Uplink Ports	13
Configure GbE Interface	14
Configure Management Port	14
Configure IP Route	15
Viewing Uplink Statistics	15
Ethernet > Downlink Ports.....	16
Ports 1-24.....	16
Viewing adapter information	16
Viewing port information.....	17
Ethernet > PoE	18
Ports 1-24.....	19
Viewing port information.....	19
4. VLAN Page	20
About the VLAN Page.....	20
VLAN > VLAN Table	20
Adding a VLAN	21
Editing a VLAN	21
Setting the default VLAN	21
Deleting VLANs.....	21
VLAN > VLAN To Port	21
Viewing VLAN port details.....	22
Assigning ports to a VLAN.....	22

Removing ports from a VLAN	22
Refreshing VLAN information	23
VLAN > Assign PVID	23
PVID Table	24
Viewing port PVID details for a VLAN	24
Adding or modifying a port PVID.....	24
Refreshing VLAN information	24
5. Admin Page	25
About the Admin Page	25
Admin > Setup	25
System Settings	26
Import/Export Configuration.....	27
View the switch configuration	27
Export configuration from the switch	27
Import configuration to the switch	27
Admin > Services.....	28
Services	28
Remote Log Server	29
Network Time Protocol	29
Spanning Tree Protocol	29
Simple Network Management Protocol	30
Admin > Terminal	31
Using the Command Line Interface	31
Adding notes to the switch	32
6. Command Line Interface	33
Command Reference	33
Upgrade Procedure	42
Displaying the current installed version	43
Incremental upgrade	43
Upgrade recovery and full version install	44
7. Troubleshooting	45

1. Overview

About this Guide

This user guide provides instructions to manage, control and monitor the switch using the Admin GUI.

This guide is intended for operating personnel (sometimes called craft persons). Users must be familiar with the basic operations of a Layer 2 switch. Access to the hardware interface is by a computer with a telnet terminal.

About the Admin GUI

The Admin GUI provides you with a simple and intuitive tool to manage, control and monitor the switch. Most operations can be performed with a click of the mouse. The Admin GUI also includes a command line interface for managing the switch.


The Admin GUI is divided into four pages, arranged in order of the frequency that you will typically access them:

System Provides a real-time overview of the system, and allows you to control downlink ports and view detailed log activities. See "About the System Page" on page 3.

Ethernet Provides switch configuration and management as well as uplink and downlink port management. See "About the Ethernet Page" on page 13.

VLAN Allows users to view, establish and assign VLANs. See "About the VLAN Page" on page 20.

Admin Allows users to setup, configure and manage the switch, enable services and configure the switch using a command line interface. See "About the Admin Page" on page 25.



Software Version

The current version of the switch software is 7.1.0.

Logging into the Switch


The screenshot shows the login interface for a Phybridge FLEX 24 PoE Switch. At the top, there is a dark blue header with the Phybridge logo and the text "FLEX 24 PoE Switch - Login". Below this, a light blue box contains a "Login" tab. Inside the tab, there are two input fields: "Username:" and "Password:". To the right of the "Password:" field is a "Log In" button.

Managing Multiple Switches

When managing multiple switches through the Admin GUI, each switch is shown as a separate browser window or tab. The window/tab title contains the switch hostname, allowing you to easily identify each switch.

Each tab title is composed of:

1. Hostname of the switch
2. Currently active page on the switch.



2. System Page

About the System Page

The System page provides high-level switch details, allowing you to monitor the system in real-time. The data provided on the System page is helpful to troubleshoot most issues you may encounter.

The System page contains three tabs:

- Overview
- Performance
- Log

System > Overview

Phylbridge FLEX 24 PoE Switch SYSTEM ETHERNET VLAN ADMIN ?

OVERVIEW PERFORMANCE LOG

System Overview

Model	FLEX 24 PoE Switch	Host Name	FLEX24
Product Number	NV-FLX-024	IP Address	192.168.10.21
Serial Number	9016300006	MAC Address	00:24:63:20:13:B7
Up Time	62 Days, 20H:7M:46S	Subnet Mask	255.255.255.0
Current Time	Wed Jul 25 2018 11:47:58 AM	Default Gateway	192.168.10.1
CPU Load	0.55	IP Address (mgmt)	192.168.1.1
Memory	Used: 43.852MB Free: 11.096MB	PSE Voltage	56 Volts
Temperature	41 C	PSE Power	Used: 0.000W Free: 528.650W
Contact	http://www.nvtpylbridge.com/support-ticket/ Tel: 1-888-901-3633 Mon-Fri 4am-7pm EST		

Ethernet Ports (Link: 1, Activity: 1)

Port	Description	PoE	Days HH:MM:SS	Mb	Port	Description	PoE	Days HH:MM:SS	Mb
1	Office 1		6 23:33:39		13	Office 3	2.0	5 11:04:25	0.0
2	Lab		6 23:43:10		14				
3	Parking Lot		20 07:36:41		15				
4	Office 2				16				
5	Pole				17				
6	Lunchroom				18				
7					19				
8			21 07:19:57		20				
9					21				
10					22				
11					23				
12					24				

LAN: Gbic1 Gbic2 **GbE1** GbE2 MGMT PoE: Used: 2.00W Available: 508.65W

System Overview

Provides an overview of the switch statistics.

System Overview			
Model	FLEX 24 PoE Switch	Host Name	FLEX24
Product Number	NV-FLX-024	IP Address	192.168.10.21
Serial Number	9016300006	MAC Address	00:24:63:20:13:B7
Up Time	62 Days, 20H:7M:46S	Subnet Mask	255.255.255.0
Current Time	Wed Jul 25 2018 11:47:58 AM	Default Gateway	192.168.10.1
CPU Load	0.55	IP Address (mgmt)	192.168.1.1
Memory	Used: 43.852MB Free: 11.096MB	PSE Voltage	56 Volts
Temperature	41 C	PSE Power	Used: 0.000W Free: 528.650W
Contact	http://www.nvtpybridge.com/support-ticket/ Tel: 1-888-901-3633 Mon-Fri 4am-7pm EST		

Model	Model.
Product Number	Product number.
Serial Number	Serial number.
Software Version	Software version.
Uptime	System uptime. Updated in real-time.
Current Time	Current date and time according to the switch. Updated in real-time.
Memory	Current used and free memory. Updated in real-time.
Temperature	Current temperature. Updated in real-time.
Host Name	Current host name. This field can be configured in Admin > Setup (see page 25).
IP Address	Current IP address. This field can be configured in Ethernet > Uplink Ports (see page 13).
MAC Address	Current MAC address.
Subnet Mask	Current subnet mask. This field can be configured in Ethernet > Uplink Ports (see page 13).
Default Gateway	Current default gateway. This field can be configured in Ethernet > Uplink Ports (see page 13).
IP Address (mgmt)	Current management port IP address. This field can be configured in Ethernet > Uplink Ports (see page 13).
PSU Capacity	Power supply maximum capacity.
POE Budget	Available power remaining at the current set voltage.
Contact	Contact information. This field can be configured in Admin > Setup (see page 25).

Ethernet Port Status

Provides the uplink and downlink port status; allows you to control power to the downlink ports.

Ethernet Ports (Link: 9, Activity: 5)									
BNC	Description	PoE	Days HH:MM:SS	Mb	BNC	Description	PoE	Days HH:MM:SS	Mb
1	Reception	4.72	23 20:09:03	0.0	13	Engineering Board Room	0.69	51 23:42:24	
2	Board Room 1				14	High Power PTZ Camera	25.53	0 01:03:04	
3	Board Room 2				15	Network Analyzer Stn			
4	Project Room 1	3.05	0 00:05:25	0.0	16	Communication Closet			
5	Project Room 2				17	Loading Bay 3	4.30	20 21:02:07	0.0
6	Kitchen								
7	Lobby	3.33	0 01						
8	Dome Camera	4.58	0 00						
9	Network Test Lab				21	Parking Level 0		0 01:03:09	
10	EMC Compliance Chamber				22	Parking Level 2			
11	Hot Air Station				23	Parking Level 3	0.97	0 01:02:05	
12	Project Room 2				24	Infrared Camera			

MAC: 00:00:1B:03:54:77

BNC 17	Mbps	Packets	Errors
RX	0	18,628,638	3
TX	0.00381	55,818,287	0

LD: 0





LAN: Gbic1 Gbic2 **GbE1** GbE2 MGMT PoE: ☐ Used: 50.36W Available: 967.14W

A downlink port summary above the port boxes indicates how many adapters are available and how many are connected to endpoints.

BNC	Port number.
Description	Description of the port for easy identification; this is configured in Ethernet > Downlink Ports (see page 16).
PoE	Watts used by the endpoint, displayed as a real-time moving bar graph. The whole width of the field is 100%: the number shown is the percentage and the bar is a visual representation.
Days HH:MM:SS	Length of uptime or downtime; see "Viewing port status" below.
Mb	Megabits per second bandwidth received from the endpoint, displayed as a real-time moving bar graph. The whole width of the field is 100%: the number shown is the percentage and the bar is a visual representation.
LAN	Uplink ports. For a breakdown of the packets received to and sent from these ports, see Ethernet > Uplink Ports (on page 13).
PoE	Total watts used by all endpoints, displayed as a real-time moving bar graph. The whole width of the field is 100%: the number shown is the percentage and the bar is a visual representation.

Viewing port status

- Hover over a port number to view port information (link details, MAC address of the main device and a historical link down count for the port). For a breakdown of the packet information, see Ethernet > Downlink Ports (see page 16).
- The **Days** field shows uptime or downtime of adapter connections: black text = uptime, gold text = downtime. This counter is reset when the port is reset.
- Port status can be easily identified by the colour and shading of the port box and number.

Colour	Port Status
 White box	Port is available with power; nothing is attached to the port.
 Grey shaded box	Port power has been manually disabled.
 Blue shaded box	Adapter is attached to the port; nothing is attached to the adapter.
 Solid blue box	Adapter is attached to the port; an IP device is connected to the adapter. You can lock the port to the currently connected IP device, on the Ethernet > Downlink Ports page (see page 16). When locked, a lock icon (🔒) appears beside the Description .
Number changes from black to red	The port number gradually changes from black to red if there is a cable fault.

Controlling power to downlink ports

You can turn the power on or off for a port.

1. Double-click a port.
2. Click **OK** to confirm that you want to turn the port power on or off.

System > Performance


All panels provide current values and the last two minutes of historical data; values are updated in real-time. Below each panel is the defined threshold (minimum or maximum) and date of the last indicator reading.



CPU Load

Legend shows the current CPU load. This value represents the number of processes waiting in queue; in a healthy environment, CPU load should not be consistently above 1.0.


Graph provides an overview of the historical CPU load.



Memory (Megabytes)

Legend shows the current memory usage, allowing you to visualize available memory.


Graph provides an overview of historical memory usage. A flat line with few peaks and valleys is normal in a healthy system. If memory usage keeps increasing, this may cause system instability. If this occurs, note the used and free values in the legend and call system support.



Power (Watts)

Legend shows the current total power consumption. Use the legend to identify the free power availability and manage it accordingly.


Graph provides an overview of the historical total power consumed by the switch and all devices connected to it. Expect variations as activities on the switch change. Peaks and valleys are normal as devices are added and removed.



Temperature (Celsius)

Legend shows the current switch temperature.

Graph provides an overview of the historical switch temperature. A flatline with few peaks and valleys is normal in a healthy system as long as the temperature remains below 55. If the temperature remains above 55, observe the physical switch environment to ensure proper ventilation and cooling.



System > Log

Use to view the system log with real-time updates. You can also add markers to the log and download the log file.

Phybridge FLEX 24 PoE Switch

SYSTEM ETHERNET VLAN ADMIN

OVERVIEW PERFORMANCE **LOG**

Apr 12 00:50:32 ntpd[216]: adjusting local clock by 51769.412611s
 Apr 12 00:50:32 ntpd[216]: adjtime failed: Invalid argument
 Apr 12 00:53:33 ntpd[216]: adjusting local clock by 51768.843620s
 Apr 12 00:53:33 ntpd[216]: adjtime failed: Invalid argument
 Apr 12 00:57:16 ntpd[216]: adjusting local clock by 51768.505426s
 Apr 12 00:57:16 ntpd[216]: adjtime failed: Invalid argument
 Apr 12 00:59:39 ntpd[216]: adjusting local clock by 51767.958877s
 Apr 12 00:59:39 ntpd[216]: adjtime failed: Invalid argument
 Apr 12 01:02:44 ntpd[216]: adjusting local clock by 51767.475223s
 Apr 12 01:02:44 ntpd[216]: adjtime failed: Invalid argument
 Apr 12 01:05:53 ntpd[216]: adjusting local clock by 51767.007707s
 Apr 12 01:05:53 ntpd[216]: adjtime failed: Invalid argument
 Apr 12 01:09:03 ntpd[216]: adjusting local clock by 51766.684010s
 Apr 12 01:09:03 ntpd[216]: adjtime failed: Invalid argument
 Apr 12 01:11:13 ntpd[216]: adjusting local clock by 51766.150512s
 Apr 12 01:11:13 ntpd[216]: adjtime failed: Invalid argument
 Apr 12 01:14:59 ntpd[216]: adjusting local clock by 51765.675624s
 Apr 12 01:14:59 ntpd[216]: adjtime failed: Invalid argument
 Apr 12 01:17:56 ntpd[216]: adjusting local clock by 51765.428534s
 Apr 12 01:17:56 ntpd[216]: adjtime failed: Invalid argument
 Apr 12 01:20:05 ntpd[216]: adjusting local clock by 51764.905236s
 Apr 12 01:20:05 ntpd[216]: adjtime failed: Invalid argument
 Apr 12 01:22:54 ntpd[216]: adjusting local clock by 51764.621549s
 Apr 12 01:22:54 ntpd[216]: adjtime failed: Invalid argument
 Apr 12 01:25:05 ntpd[216]: adjusting local clock by 51764.297431s
 Apr 12 01:25:05 ntpd[216]: adjtime failed: Invalid argument
 Apr 12 01:28:09 ntpd[216]: adjusting local clock by 51763.565689s
 Apr 12 01:28:09 ntpd[216]: adjtime failed: Invalid argument
 Apr 12 01:31:50 ntpd[216]: adjusting local clock by 51763.039390s
 Apr 12 01:31:50 ntpd[216]: adjtime failed: Invalid argument
 Apr 12 01:36:03 ntpd[216]: adjusting local clock by 51762.680340s
 Apr 12 01:36:03 ntpd[216]: adjtime failed: Invalid argument

Get last: 60 SUBMIT Log entries containing: and SEARCH


MARKER

Selecting the number of events to display

1. In the **Get last** list, select the number of events to display on the Log tab. You can enter a value or use the arrows to increase/decrease the value in increments of 10.
2. Click **SUBMIT**. The Log tab is updated immediately.

Searching Log entries

1. You can enter multiple search terms in the “Log entries containing” window. Search terms are case sensitive and spaces are significant.
2. Click **SEARCH**. The Log tab is updated immediately.
3. Search results are shown in green text and the log entries are in black.



Adding markers to the log

You can add markers to mark particular points in the log. For example, you could use markers to mark the start and end points of certain events you would like to monitor. Markers are added to the log shown on the Log tab and also to the log stored on the remote log server.

1. Enter the marker text.
2. Click **MARKER**. The marker is added to the log.

Downloading the log file

Click **DOWNLOAD LOG FILE** to save a copy of the log file shown on the Log tab. The filename for the exported file uses the convention **<hostname>.log** (example: switch.log). This allows you to easily identify which switch the file was exported from.

NOTE

You can continue using the Admin GUI while the file is downloading.

3. Ethernet Page

About the Ethernet Page


The Ethernet page allows you to monitor the health of the network, configure the switch network interface, and manage uplink and downlink ports.


The Ethernet page contains three tabs:

- Uplink Ports
- Downlink Ports
- PoE


Ethernet > Uplink Ports

IMPORTANT

Changes that you apply are temporary. If you do not click  to save changes, any changes made on this tab will be lost after a system reboot.



Phybridge FLEX 24 PoE Switch SYSTEM ETHERNET VLAN ADMIN ?

UPLINK PORTS DOWNLINK PORTS PoE (56V) 

Configure GbE Interface

IP Address: 192.168.10.243

Net Mask: 255.255.255.0

Broadcast: 192.168.10.255

GbE1 Medium: Copper ▾

GbE2 Medium: Copper ▾

APPLY

Configure Management Port

IP Address: 192.168.100.1

Net Mask: 255.255.255.0

Broadcast: 192.168.100.255

Default PVID: 1001

APPLY

Configure IP Route

Default Gateway: 192.168.10.1 Interface: GbE ▾


APPLY

Uplink Statistics

Port	Receive Packet Counters				Transmit Packet Counters			
	Broadcast	Multicast	Unicast	Errors	Broadcast	Multicast	Unicast	Errors
GbE1	127052766	90030130	475445991	0	2095535	7720989	618344580	0
	Total: 692,528,887				Total: 628,161,104			
GbE2	0	0	0	0	0	2243876	0	0
	Total: 0				Total: 2,243,876			
MGMT	0	0	0	0	0	0	0	0
	Total: 0				Total: 0			

Configure GbE Interface

Use to configure the switch network interface.



The screenshot shows a web form titled "Configure GbE Interface". It contains five input fields: "IP Address" with the value "192.168.10.89", "Net Mask" with "255.255.255.0", "Broadcast" with "192.168.10.255", "GbE1 Medium" with a dropdown menu showing "Copper", and "GbE2 Medium" with a dropdown menu showing "Copper". An "APPLY" button is located at the bottom right of the form.

1. Modify any of the fields (IP Address, Net Mask, Broadcast, GbE1 Medium, GbE2 Medium).


Notes:

- If the IP address is changed, the new IP address will be required to log back into the box.
- The management port IP address and the uplink port IP address should never be on the same subnet. This ensures the management port can still be reached if the data LAN experiences issues.

2. Click APPLY.

Configure Management Port

Use to configure the management port IP address.



The screenshot shows a web form titled "Configure Management Port". It contains four input fields: "IP Address" with the value "192.168.1.1", "Net Mask" with "255.255.255.0", "Broadcast" with "192.168.1.255", and "Default PVID" with "1001". An "APPLY" button is located at the bottom right of the form.

1. Modify any of the fields (IP Address, Net Mask, Broadcast, Default PVID).

Notes:

- If the IP address is changed, the new IP address will be required to log back into the box via the management port.
- The management port IP address and the uplink port IP address should never be on the same subnet. This ensures the management port can still be reached if the data LAN experiences issues.
- The default PVID (which is the default VLAN ID for the management port) can be changed using the command line interface in Admin > Terminal (see page 31).

2. Click **APPLY**.

Configure IP Route

Use to configure the default gateway IP address and to select the interface to apply it to.

Configure IP Route

Default Gateway:
Interface:

APPLY

1. Modify any of the fields (Default Gateway, Interface).

Notes:

- The Default Gateway can be assigned to only one interface. The interface can be either GbE or Mgmt.
- If the IP address is changed, the new IP address will be required to log back into the box via the management port.
- The management port IP address and the uplink port IP address should never be on the same subnet. This ensures the management port can still be reached if the data LAN experiences issues.

2. Click **APPLY**.


Viewing Uplink Statistics

Displays a breakdown of packets received to and transmitted from the LAN ports.

Uplink Statistics								
Port	Receive Packet Counters				Transmit Packet Counters			
	Broadcast	Multicast	Unicast	Errors	Broadcast	Multicast	Unicast	Errors
GbE1	116870	2593	527090	0	99429	286721	522730	0
	Total: 646,553				Total: 908,880			
GbE2	0	0	0	0	0	6	0	0
	Total: 0				Total: 6			
MGMT	0	0	0	0	0	0	0	0
	Total: 0				Total: 0			

Ethernet > Downlink Ports

IMPORTANT

Changes that you apply are temporary. If you do not click  to save changes, any changes made on this tab will be lost after a system reboot.

Phybridge FLEX 24 PoE Switch										
SYSTEM			ETHERNET			VLAN			ADMIN	
UPLINK PORTS			DOWNLINK PORTS			PoE (56V)				
Port			Description	MAC Address	Days HH:MM:SS	RX Packets		TX Packets		LD
						Total	Error	Total	Error	
1			A Office 1			3,935	1	1,234,250	0	5
2			A Lab			32	1	1,230,531	0	3
3			A Parking Lot			134	0	1,231,398	0	1
4			A Office 2			0	0	1,230,521	0	
5			A Pole			0	0	1,230,521	0	
6			A Lunchroom			0	0	1,230,521	0	
7			A			0	0	1,230,521	0	
8			A			153	1	1,231,467	0	2
9			A			0	0	1,230,521	0	
10			A			0	0	1,230,521	0	
11			A			0	0	1,230,521	0	
12			A			0	0	1,230,521	0	
13			10 Office 3	DCEB948DEEE6	5 11:05:16	81,189	1	1,429,343	0	2
14			A			0	0	1,230,521	0	
15			A			0	0	1,230,521	0	
16			A			0	0	1,230,521	0	
17			A			0	0	1,230,521	0	
18			A			0	0	1,230,521	0	
19			A			0	0	1,230,521	0	
20			A			0	0	1,230,521	0	
21			A			0	0	1,230,521	0	
22			A			0	0	1,230,521	0	
23			A			0	0	1,230,521	0	
24			A			0	0	1,230,521	0	

Link: 1; Activity: 1; Power: 0.000W; Temperature: 40C

Ports 1–24

Used to manage the downlink ports.

Viewing adapter information

Adapter summary information is shown below the port details table and includes the number of adapters connected, the number of endpoints connected to the adapters, the total power being consumed, and the temperature of the switch. This information is updated in real-time.

Viewing port information

The following information is shown for each port:

BNC

Port number. Click to view ethernet statistics for the port. These statistics include non-zero data only (does not include inactive).



Ethernet Statistics - Port 20

```
8078796      snmpIfInOctets (stat 0)
23556        snmpIfInNUcastPkts (stat 2)
263          snmpIfInDiscards (stat 3)
30578158     snmpIfOutOctets (stat 6)
12           snmpIfOutUcastPkts (stat 7)
87508        snmpIfOutNUcastPkts (stat 8)
23556        snmpDot1dTpPortInFrames (stat 18)
87520        snmpDot1dTpPortOutFrames (stat 19)
47239        snmpEtherStatsMulticastPkts (stat 22)
63825        snmpEtherStatsBroadcastPkts (stat 23)
3391         snmpEtherStatsPkts64Octets (stat 26)
```



Control power to the port. Click to turn the power on or off. Dark blue = on, light blue = off.


or

Click  or  at the top right of the tab to turn all ports on or off.



Indicates the link status. Dark blue = linked, light blue = not linked. Click to reset the port.

or

Click  at the top right of the tab to reset all ports at once.

Description

Description of the port for easy identification on the System > Overview page; click on a description to edit it. The Description is shown in blue text while editing. Remember to save any changes.

Project Room 3

MAC Address

MAC address of the IP device connected to the adapter associated with this port.





or



Indicates whether a read-only link exists between the adapter and the switch. Click to lock or unlock MAC address to the port.

or

Click  or  at the top right of the tab to lock/unlock all ports at once.

Days


HH:MM:SS

Length of time the device has been connected to the adapter.

RX Packets	Number of packets received and transmitted from this port, and number of errors, captured in real-time and updated approximately every second. Error counts should be low in comparison to the number of packets. Any negative values should be interpreted as zero. Hover over the Total to see a breakdown of Multicast, Broadcast, and Unicast packets.
TX Packets	
LD	Number of link-down events (these occur when the adapter goes through a link transition). A high number may indicate physical errors. Click to view link transition statistics for the port. This historical information can help you to identify patterns of downtime (e.g. frequency, consistent time, duration, etc.).

Ethernet > PoE

The PoE tab displays the current PoE voltage.


Phybridge FLEX 24 PoE Switch
 SYSTEM
ETHERNET
VLAN
ADMIN
?
⌵

UPLINK PORTS
DOWNLINK PORTS
PoE (56V)
⌵

Used: 2.000W | Available: 528.650W | Max: 16.791W on Wed Jul 04 2018 5:40:52 AM


Port	PoE	Description	Power Consumption			Maximum Power	
			mA	W	%	W	Timestamp
1	MANUAL	Office 1				2.9	Wed Jul 18 2018 12:25:22 PM
2	AUTO	Lab				2.6	Wed Jul 18 2018 12:29:16 PM
3	AUTO	Parking Lot				7.4	Thu Jul 05 2018 5:24:14 AM
4	AUTO	Office 2					
5	AUTO	Pole					
6	AUTO	Lunchroom					
7	AUTO						
8	AUTO					7.4	Wed Jul 04 2018 5:42:11 AM
9	MANUAL OFF						
10	AUTO						
11	AUTO						
12	AUTO						
13	MANUAL	Office 3	36.0	2.0	4	2.2	Tue Jul 17 2018 9:34:01 AM
14	AUTO						
15	AUTO						
16	AUTO						
17	AUTO						
18	AUTO						
19	AUTO						
20	AUTO						
21	AUTO						
22	AUTO						
23	AUTO						
24	AUTO						

Ports 1–24

Used to display power usage per port.

Viewing port information

The following information is shown for each port:

Power Consumption	
BNC	Port number. Click to view ethernet statistics for the port. These statistics include non-zero data only (does not include inactive).
Description	Description of the port for easy identification on the System > Overview page.
mA	Current power consumption in milliamps of the port.
W	Current power consumption in watts of the port.
%	Percentage of power usage. The whole width of the field is 100%: the number shown is the percentage and the bar is a visual representation.
Maximum Power	
W	Maximum power in watts that the port had consumed.
Timestamp	Timestamp of when the maximum power on that port has been consumed.
	Click to reset the Maximum power statistic.

NOTE

WHITE BACKGROUND — Port is not a member.


BLUE BACKGROUND — Port is a member.

BLACK TEXT — Port is a PVID.

GREY TEXT — Port is only a member of the VLAN.

Adding a VLAN

You can add a new static VLAN.

1. Click **ADD**.
2. Enter the VLAN number and click **OK**.
3. Click  to save your changes.
4. To assign ports to the VLAN, click the VLAN and click **EDIT**.

The VLAN to PORT tab appears with the VLAN panel open. You can now assign ports to the VLAN (see "VLAN > VLAN To Port" on page 21).


Editing a VLAN

1. Click a VLAN. The selected VLAN will now be enclosed in a black border.
2. Click **EDIT**.

The VLAN to PORT tab appears with the VLAN panel open. You can now assign ports to the VLAN (see "VLAN > VLAN To Port" on page 21).

Setting the default VLAN

The default VLAN is used for ports not assigned to any other VLAN. VLAN 1 is the system default; however, you can select a different default VLAN if desired.

1. Click the VLAN you want to set as the default.
2. Click **DEFAULT**.
3. Click  to save your changes.


Deleting VLANs

You can delete a static VLAN; you cannot delete the default VLAN.

1. Click the VLAN you want to delete, then click **DELETE**.

or

Click **DELETE ALL** to delete all static VLANs.

2. Click  to save your changes.


VLAN > VLAN To Port


Use to assign ports to VLANs. You can add/remove individual ports from a VLAN or you can add/remove all ports at once.

NOTE

Use the VLAN Table tab to create and remove VLANs (see page 20).

IMPORTANT


Changes that you apply are temporary. If you do not click  to save changes, any changes made on this tab will be lost after a system reboot.

**Viewing VLAN port details**

Each VLAN is shown as a separate panel.

1. Click the panel header (the VLAN number) to expand the panel.
2. A table with all ports is shown. The ports that are members of the VLAN have a shaded background. Ports that are not members have a white background.


Assigning ports to a VLAN

1. Click one or more ports in the VLAN panel.
or
Click **ALL** to select all ports. (Click **NONE** to clear all ports.)
A checkmark is shown on selected ports.
2. Click **ADD**. The added ports now have a shaded background.
3. Click  to save your changes.

Removing ports from a VLAN

1. Click one or more ports in the VLAN panel.
or
Click **ALL** to select all ports. (Click **NONE** to clear all ports.)

A checkmark is shown on selected ports.

2. Click **REMOVE**. The removed ports now have a white background.
3. Click  to save your changes.


Refreshing VLAN information


VLAN information on this tab is not updated in real-time. Click **REFRESH** to update the information (for example, to see any changes made by other users).

VLAN > Assign PVID

Use to assign the primary VLAN ID to ports. VLANs created in the VLAN Table tab can be used for PVID tagging. For details on adding and removing VLANs, see "VLAN > VLAN Table" on page 20.

IMPORTANT

Changes that you apply are temporary. If you do not click  to save changes, any changes made on this tab will be lost after a system reboot.



The screenshot shows the NVT Phybridge FLEX 24 PoE Switch web interface. The top navigation bar includes tabs for SYSTEM, ETHERNET, VLAN, and ADMIN. The main content area has three sub-tabs: VLAN TABLE, VLAN to PORT, and ASSIGN PVID (which is currently selected). Below the sub-tabs is the "PVID Table" section, which contains two tables. The first table shows PVID assignments for GbE1 and GbE2 ports. The second table shows PVID assignments for ports 1 through 24. Below the tables is a section for "VLAN 1" with a "Ports" table showing checkboxes for each port. At the bottom of the "VLAN 1" section are buttons for ALL, NONE, ASSIGN, and REFRESH. Below this is a section for "VLAN 45".

PORT	GbE1	GbE2
PVID	1	1

PORT	1	2	3	4	5	6	7	8	9	10	11	12
PVID	1	1	1	1	1	1	1	1	1	1	1	1

PORT	13	14	15	16	17	18	19	20	21	22	23	24
PVID	1	1	1	1	1	1	1	1	1	1	1	1

VLAN 1

Ports												
GbE1	1	2	3	4	5	6	7	8	9	10	11	12
GbE2	13	14	15	16	17	18	19	20	21	22	23	24

ALL NONE ASSIGN REFRESH

VLAN 45

PVID Table

Static panel showing each port's PVID. Each port has only one PVID. By default, every port is assigned the system default VLAN as the PVID. (The default VLAN is set on the VLAN Table tab; see page 20.)

Viewing port PVID details for a VLAN


Each VLAN is shown as a separate panel.

1. Click the panel header (the VLAN number) to expand the panel.
2. A table with all ports is shown. The ports that belong to the PVID have a shaded background. Ports that do not belong to the PVID have a white background.

Adding or modifying a port PVID

IMPORTANT

The switch may lose connectivity if you change the PVID of the GbE ports. Use caution when considering making changes to these ports.

1. Click one or more ports in the VLAN panel.
or
Click **ALL** to select all ports, with the exception of GbE1 and GbE2. (Click **NONE** to clear all ports.)
A checkmark is shown on selected ports.
2. Click **ASSIGN**. The new PVID is established and the added ports now have a shaded background.
3. Click  to save your changes.

Refreshing VLAN information

VLAN information on this tab is not updated in real-time. Click **REFRESH** to update the information (for example, to see any changes made by other users).

5. Admin Page

About the Admin Page

The Admin page allows you to configure switch settings, control services, configure servers, and use the command line interface.

The Admin page contains three tabs:

- Setup
- Services
- Terminal

Admin > Setup

Phybridge FLEX 24 PoE Switch

SYSTEM ETHERNET VLAN ADMIN

SETUP SERVICES TERMINAL

System Settings

Host Name: FLEX24

Date(YY-MM-DD): 18-07-25

Time(HH:MM): 15:50

Time Zone: Africa/Abidjan

PoE (Volts): 56

Admin Password: Confirm Password:

Technical Support: <http://www.nvtphybridge.com/support-ticket/> Tel:1-888-901-3633 Mon-Fri 4an

Reset Counters:

Configuration File

Display Configuration in a New Window:

Download Configuration from the Switch:

No File Selected

System Settings

Use to configure basic switch settings. After modifying a setting, click **APPLY**. The updates will be applied immediately to the switch.

System Settings

Host Name: FLEX

Date(YY-MM-DD): 16-05-09

Time(HH:MM): 14:05

Time Zone: Africa/Abidjan

PoE (Volts): 56

Admin Password: Confirm Password:

Technical Support: http://www.phybridge.com/support/flex/ Tel:1-888-901-3633 Mon-Fri 8am-6pm

Reset Counters:


Host Name	Switch host name.
Date	Switch date (YY-MM-DD), time (HH:MM), and time zone.
Time	
Time Zone	
PoE Voltage	Adjust the power available to the device connected. Defaults to 56V which is the recommended voltage for PoE. Range from 48 – 56V; use slider to adjust. Click APPLY .
Admin Password	Admin GUI password. To change the password, enter the new password in both of these fields, then click APPLY .
Confirm Password	
Password	
NOTE You will be prompted to log back into the Admin GUI after changing the password.	
Technical Support	Technical Support contact information.
Reset Diagnostic Counters	Reset only the diagnostic counters.
Reset Uplink Counters	Reset all counters for the gigabit ports (transmit/receive counts, errors, broadcasts, and multicasts).
Reset Downlink Counters	Reset all downlink counters (transmit/receive counts and errors).

Import/Export Configuration

You can import or export the current switch configuration. This allows you to download the existing configuration, make changes, and then upload the new configuration.

IMPORTANT

When editing the configuration file, the existing syntax must be strictly followed or you may lose access to the switch. The file must be saved in Unix file format; using a program such as dos2unix/unix2dos or Notepad++ to edit the file is recommended.



The screenshot shows a web interface titled "Configuration File". It contains three main sections: "Display Configuration in a New Window:" with a "DISPLAY" button; "Download Configuration from the Switch:" with a "DOWNLOAD" button; and a file selection section with a "SELECT FILE" button, a text input field containing "No File Selected", and an "UPLOAD" button.

View the switch configuration

To view the current switch configuration, click **DISPLAY**. You can copy the text from this window to paste into another application or document.

Export configuration from the switch

1. Click **DOWNLOAD** to save a copy of the current switch configuration.
The filename for the exported file uses the convention **<hostname>.cfg** (example: switch.cfg). This allows you to easily identify which switch the file was exported from.
2. You can modify the following settings in the configuration file:
 - switch host name and IP address
 - information for the NTP Server, SNMP Service, Syslog Server, and VLAN, and Port Enable/Disable

Import configuration to the switch

1. To import or upload the modified configuration file to the switch, click **SELECT FILE** and select the configuration file to upload.
2. Verify that you have selected the correct file and click **UPLOAD**. When the upload is complete, the configuration changes are applied immediately to the switch.

Admin > Services

Phybridge FLEX 24 PoE Switch SYSTEM ETHERNET VLAN ADMIN ?

SETUP **SERVICES** TERMINAL

Service:	TELNET	HTTP	LOG	LLDP	NTP	STP	SNMP	Description
Enable	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Enable on System Startup
Run	<input type="button" value="STOP"/>	<input type="button" value="STOP"/>	<input type="button" value="STOP"/>	<input type="button" value="START"/>	<input type="button" value="START"/>	<input type="button" value="START"/>	<input type="button" value="START"/>	Start or Stop this Service

Remote Log Server

IP Address: Port:

Network Time Protocol

IP Address: NTP Servers:

Spanning Tree Protocol

Switch Protocol from: Bridge Priority:

Simple Network Management Protocol

Receiver IP Address: Enable Receiver ☒

Services

Use to control all the services for the switch including TELNET, HTTP, LOG, LLDP, NTP, STP and SNMP.

Service:	TELNET	HTTP	LOG	LLDP	NTP	STP	SNMP	Description
Enable	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input checked="" type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	<input type="checkbox"/>	Enable on System Startup
Run	<input type="button" value="STOP"/>	<input type="button" value="STOP"/>	<input type="button" value="STOP"/>	<input type="button" value="START"/>	<input type="button" value="START"/>	<input type="button" value="START"/>	<input type="button" value="START"/>	Start or Stop this Service

Enable Click to enable/disable a service. This determines whether the service is enabled or disabled on system startup. The Log service is always enabled.

IMPORTANT

If you disable the HTTP service, the Admin GUI will not function after a reboot. If you stop the HTTP service, you will instantly lose connectivity to the Admin GUI.

Run Click to start or stop a service. Note that the start or shutdown of services is not instantaneous and may take up to one minute.

Remote Log Server

Use to set up a remote log server. Changes are applied immediately.




The screenshot shows the 'Remote Log Server' configuration window. It contains two input fields: 'IP Address' with the value '1.1.1.1' and 'Port' with the value '514'. Each input field has an 'APPLY' button next to it.

1. Enter the IP address of the remote log server and click **APPLY**.
2. (Optional) Change the port number and click **APPLY**. The default port number is 514.

Network Time Protocol

Use to configure multiple NTP servers.



The screenshot shows the 'Network Time Protocol' configuration window. It features an 'IP Address' input field with an 'ADD' button. To the right, there is an 'NTP Servers' section with a dropdown menu showing a list of IP addresses: 216.235.14.36, 216.235.14.36 (highlighted), 96.44.157.90, 96.44.142.5, 66.178.0.74, and 208.87.120.127. A 'REMOVE' button is located to the right of the dropdown.

1. To add a server, enter the IP address and click **ADD**.
2. To remove a server, select a server from the list and click **REMOVE**.

Spanning Tree Protocol

Use to change the spanning tree protocol. The switch supports classic STP and RSTP (rapid spanning tree protocol); the default is RSTP.



The image shows a configuration panel for the Spanning Tree Protocol. It has a title bar 'Spanning Tree Protocol'. Below the title bar, there are two main sections. The first section is 'Switch Protocol from' followed by a button labeled 'RSTP to STP'. The second section is 'Bridge Priority:' followed by a text input field containing '32768' and an 'APPLY' button.


1. To change the protocol, click the **Switch Protocol** button.
The button name changes based on the currently selected protocol. For example, if the current protocol is RSTP, the option "Switch Protocol from RSTP to STP" will be shown.
2. To change the bridge priority, use the up and down arrows to increase/decrease the priority in increments of 4096, then click **APPLY**.

CAUTION

Enabling STP in a live network will cause service disruptions to end users while the network is converging. To avoid impacting users, enabling of STP should be conducted outside of core hours or during a scheduled maintenance period. Consult the MCD Resiliency Guidelines for information on how to optimally configure STP/RSTP.

Simple Network Management Protocol

Use to modify the simple network management protocol.



The image shows a configuration panel for the Simple Network Management Protocol. It has a title bar 'Simple Network Management Protocol'. Below the title bar, there are two main sections. The first section is 'Receiver IP Address:' followed by a text input field containing '1.1.1.1' and an 'APPLY' button. The second section is 'Enable Receiver' followed by a checked checkbox.

1. To change the receiver IP address, enter the address and click **APPLY**.
2. To enable/disable the receiver, click the **Enable Receiver** checkbox.

Admin > Terminal

The Terminal tab provides you with a command line interface you can use to configure the switch and diagnose switch issues. You can also use this tab to add notes to the switch.

Phybridge FLEX 24 PoE Switch

SYSTEM ETHERNET VLAN ADMIN

SETUP SERVICES **TERMINAL**

Command: pal-

FLEX> service-telnet
Usage: pal-service-telnet {start|stop|restart|enable|disable}

FLEX> show-gigaport

port	medium	link	speed	scan	autoneg	stp
mgmt	copper	down	-	SW	Yes	Forward
GbE1	copper	up	1G	SW	Yes	Forward
GbE2	copper	down	-	SW	Yes	Forward

SAVE

Scratch Pad

Use this area to capture notes about the switch.
These notes are persistent and will survive a reset or power cycle.

SAVE

Using the Command Line Interface

1. Double-click in the **Command** field to see a list of available commands, or type the first few characters of a command to filter the list.
2. Click a command in the list to select it.
3. If necessary, enter any options for the command.

NOTE

See "Command Reference" on page 33 for a list of command options and syntax.

4. Press **ENTER** to run the command.

The results of the command appear in the area below the command. When a new command is run, the results are appended to the results from the previous command.

You can now do the following:

- Modify the text in the results area (make changes, delete text, add comments, copy and paste, etc.). Right-click in the results area to view editing options such as copy, paste and spell-check.
- Click **SAVE** to save the results in a text file. The filename for the exported file uses the convention **hostname_terminal_date_time.txt**. This allows you to easily identify which switch the file was exported from.

Adding notes to the switch

You can save notes on the switch. These notes are seen by all operators with access to the Admin GUI.

1. Type a note in Scratch Pad area. You can modify the note the same way you can modify the command results (make changes, delete text, add comments, copy and paste, etc.). Right-click in the Scratch Pad area to view editing options such as copy, paste and spell-check.
2. Click **SAVE**.

6. Command Line Interface

Command Reference

The following commands can be used in the command line interface in Admin > Terminal (see page 31).

Notes:

- Commands must be entered exactly as shown in the Usage column.
- <> denote single-value entries of a specific item, as explained within the brackets.
- { } denote a set or list or range of entries for a specific item.
- [] denote an optional entry.
- If you enter a command using incorrect syntax, the correct syntax will be shown.
- If you enter incorrect values for a command, you will receive a message stating that the values are not within the acceptable range.

Command	Purpose	Usage	Usage Notes
pal	Main interface for PAL.	pal help {cmd short long configure examine persistent}	
pal-conf-edit	Modify user persistent configuration.	pal-conf-edit {show clear} pal-conf-edit delete<LINENUMBER>	<LINENUMBER> is a single-value entry of the line number you wish to delete.
pal-conf-export	Export/import persistent user configuration into/from tmp/switch.cfg.	pal-conf-export {export import}	
pal-conf-save	Save the configuration of the switch.	pal-conf-save	
pal-service-http	Enable or disable HTTP service on the switch.	pal-service-http {start stop restart enable disable}	
pal-service-lldp	Enable or disable LLDP service on the switch.	pal-service-lldp {start stop restart show enable disable} pal-service-lldpshow {1-24 all}	

Command	Purpose	Usage	Usage Notes
pal-service-log	Configure, enable or disable LOG service on the switch.	pal-service-log {start stop restart} pal-service-log remote-syslog-show pal-service-log remote-syslog-ip <IP> pal-service-log remote-syslog-port <PORT>	<p><IP> is a single-value entry of the IP address of the target syslog server.</p> <p><PORT> is a single-value entry of the syslog port number on the remote syslog server. The default is port 514.</p> <p>NOTE If you change the syslog remote IP, you are required to restart the log service.</p>
pal-service-ntp	Enable or disable NTP service on the switch.	pal-service-ntp {start stop restart enable disable}	
pal-service-snmp	Enable or disable SNMP service on the switch.	pal-service-snmp {start stop restart enable disable} pal-service-snmp receiver {enable disable show} pal-service-snmp receiver-ip <ADDRESS>	
pal-service-stp	Enable or disable STP service on the switch.	pal-service-stp {GbE1 GbE2} {enable disable} pal-service-stp service {start stop enable disable} pal-service-stp proto {stp rstp} pal-service-stp port-priority <VALUE> pal-service-stp showbridge pal-service-stp showcfg {all bridge-priority protocol age forward-delay GbE1-cost GbE2-cost} pal-service-stp age <6-40> pal-service-stp forward-delay <4-30> pal-service-stp port-cost {GbE1 GbE2} <0-65536>	<p><VALUE> is a single-value entry of the priority you wish to assign. This value ranges from 0-61440 and can be incremented by 4096. The default is 32768.</p>

Command	Purpose	Usage	Usage Notes
pal-service-telnet	Enable or disable telnet service on the switch.	pal-service-telnet {start stop restart enable disable}	
TACACS	Enable or disable TACAS AAA service on the switch.	pal-service-security {show tacacs} pal-service-security tacacs {show enable disable} pal-service-security tacacs server1 <IP_ADDR IP_ADDR:PORT HOSTNAME HOSTNAME:PORT> pal-service-security tacacs secret1 <STRING> pal-service-security tacacs server2 <IP_ADDR IP_ADDR:PORT HOSTNAME HOSTNAME:PORT> pal-service-security tacacs secret2 <STRING> pal-service-security tacacs server3 <IP_ADDR IP_ADDR:PORT HOSTNAME HOSTNAME:PORT> pal-service-security tacacs secret3 <STRING> pal-service-security tacacs server4 <IP_ADDR IP_ADDR:PORT HOSTNAME HOSTNAME:PORT> pal-service-security tacacs secret4 <STRING> pal-service-security tacacs timeout <SECONDS> pal-service-security tacacs accounting {on off}	
Radius	Enable or disable Radius service on the switch.	pal-service-security {show radius} pal-service-security radius {show enable disable} pal-service-security radius server1 <IP_ADDR IP_ADDR:PORT HOSTNAME HOSTNAME:PORT> pal-service-security radius secret1 <STRING>	

Command	Purpose	Usage	Usage Notes
pal-set-bridged	Switch between managed and unmanaged modes.	pal-set-bridged {bridged/outband/disable}	<p>Bridged Mode: All network services disabled and no management via ethernet.</p> <p>Outband Mode: All network services on GbE disabled. Management available via MGMT port.</p> <p>Disabled: Normal operation.</p>
pal-set-contact	Update the point of contact for the switch.	pal-set-contact <CONTACT>	<CONTACT> is a single-value entry of the person's name that will be the point of contact for the switch.
pal-set-gigaport	Enable or disable uplink ports on the switch; switch between copper and fiber interfaces; add, remove, and set the default VLAN of the gigaports.	pal-set-gigaport {GbE1 GbE2 mgmt} {enable disable} pal-set-gigaport {GbE1 GbE2} {copper fiber} pal-set-gigaport GbE add-vlan <VLANID> {tagged untagged} pal-set-gigaport GbE remove-vlan <VLANID> pal-set-gigaport GbE default-vlan <VLANID>	<VLANID> is a single-value entry of the VLANID you wish to configure.
pal-set-l2age	Set the value for the L2 age timer.	pal-set-l2age <SECONDS>	
pal-set-port	Enable or disable downlink ports 1-24.	pal-set-port <RANGE> {on off}	<RANGE> is a single-value entry of the port you wish to configure. This value ranges from 1-24.

Command	Purpose	Usage	Usage Notes
pal-set-port-counters-clear	Clear various counters and alarms.	pal-set-port-counters-clear{alarms uplink downlink linkdowns poe}	
pal-set-snmp	Set SNMP system values.	pal-set-snmp sysdescr <STRING> pal-set-snmp rdcommunity <STRING> pal-set-snmp wrcommunity <STRING> pal-set-snmp location <STRING> pal-set-snmp contact <STRING>	<STRING> can not contain special characters.
pal-set-staticmac	Lock MAC addresses to specific ports.	pal-set-staticmac unlock {<1-24> all} pal-set-staticmac lock {<1-24>} <MAC> [VLAN] pal-set-staticmac lock all	<MAC> must be specified with xx:xx:xx:xx:xx:xx notation. If VLAN is unspecified, pvid is used.
pal-set-port-vlan	Set and remove VLAN settings from a downlink port. Note that you must first use the command pal-set-vlan create 200.	pal-set-port-vlan <RANGE> add-vlan <VLANID> {tagged untagged} pal-set-port-vlan <RANGE> remove-vlan <VLANID> pal-set-port-vlan <RANGE> default-vlan <VLANID>	<RANGE> is a single-value entry of the port you wish to configure. This value ranges from 1-24. <VLANID> is a single-value entry of the VLAN ID you wish to configure.
pal-set-sys-date	Set the date and time on the switch. The clock is a 24 hour clock.	pal-set-sys-date {YYYY-MM-DD}	{YYYY-MM-DD} is a range of dates, where YYYY represents the year (e.g. 1988), MM represents the month (e.g. 02 for February), and DD represents the day (e.g. 19).
pal-set-sys-gateway	Set the gateway IP of the switch.	pal-set-sys-gateway {GbE mgmt} <GATEWAY>	<GATEWAY> can only be assigned to 1 interface at a time.

Command	Purpose	Usage	Usage Notes
pal-set-sys-hardreset pal-set-sys-reboot	Reboot the switch.	pal-set-sys-hardreset or pal-set-sys-reboot	
pal-set-sys-hostname	Set the hostname of the switch. Note that the following special characters are not supported: &*()".	pal-set-sys-hostname <HOSTNAME>	<HOSTNAME> is a single-value entry of the hostname you wish to configure.
pal-set-sys-ip	Set the IP of the switch.	pal-set-sys-ip GbE <IPADDRESS> <NETMASK> <BROADCAST> pal-set-sys-ip mgmt <IPADDRESS> <NETMASK> <BROADCAST>	<IPADDRESS> , <NETMASK> , and <BROADCAST> are all single-value entries for these addresses.
pal-set-sys-led	Change downlink port LED status meaning on front of the unit..	pal-set-sys-led {off activity link}	Off: Disable port LEDs. Activity: LEDs flash with traffic. Link: LEDs solid when link is established.
pal-set-sys-passwd	Change the user password.	pal-set-sys-passwd<USERNAME><PASSWORD>	<USERNAME> is a single-value entry of the username of the switch. <PASSWORD> is a single-value entry of the new password of the switch.
pal-set-sys-ping	Send ICMP ECHO_REQUEST packets to network hosts to verify IP-level connectivity.	pal-set-sys-ping <IP HOST>	

Command	Purpose	Usage	Usage Notes
pal-set-sys-stimeout	Set the console session timeout.	pal-set-sys-stimeout <SECONDS>	
pal-set-sys-time	Set the system time of the switch.	pal-set-sys-time {HH:MM}	{HH:MM} is a range of times, where HH represents the hour (e.g. 15 is 3:xx pm), and MM represents the minutes (e.g. 45 is x:45).
pal-set-sys-timezone	Set the system timezone of the switch.	pal-set-sys-timezone list pal-set-sys-timezone timezone <TIMEZONE>	Using list will display timezone options, then set using appropriate choice.
pal-set-vlan	Create and delete VLANs on the switch.	pal-set-vlan create <VLANID> pal-set-vlan delete <VLANID> pal-set-vlan default<VLANID> pal-set-vlan clear	<VLANID> is a single-value entry of the VLAN ID you wish to configure.
pal-set-voltage	Set the voltage of the downlink ports.	pal-set-voltage <DECIVOLTS>	<DECIVOLTS> must be between 480 and 560. Example: 495 Decivolts is 49.5 Volts.
pal-show-bridged	Display the current bridged mode.	pal-show-bridged	
pal-show-contact	Show the name of the person who is the point of contact for the switch.	pal-show-contact	
pal-show-gigaport	Show uplink port status.	pal-show-gigaport	

Command	Purpose	Usage	Usage Notes
pal-show-l2age	Show the value of the L2 age timer in seconds.	pal-show-l2age	
pal-show-port	Show downlink port status and statistics.	pal-show-port <RANGE>	<RANGE> is a single-value entry of a port you wish to configure. This value ranges from 1-24.
pal-show-port-counters	Show port counters.	pal-show-port-counters <RANGE>	<RANGE> is a single-value entry of a port you wish to configure. This value ranges from 1-24.
pal-show-port-statistics	Show port statistics.	pal-show-port-statistics <RANGE>	<RANGE> is a single-value entry of a port you wish to configure. This value ranges from 1-24.
pal-show-port-status	Show port status.	pal-show-port-status <RANGE>	<RANGE> is a single-value entry of a port you wish to configure. This value ranges from 1-24.
pal-show-service-status	Show the current state of a specified service (or all services) on the switch.	pal-show-service-status {all telnet http log lldp ntp stp snmp}	
pal-show-service-startup	Show the state of a specified service (or all services) at start-up.	-show-service-startup {all telnet http lldp ntp stp snmp}	

Command	Purpose	Usage	Usage Notes
pal-show-snmpp	Display the set SNMP system values.	pal-show-snmpp {sysdescr rdcommunity wrcommunity location contact}	
pal-show-staticmac	Show port MAC lock status.	pal-show-staticmac {<1-24> all}	
pal-show-sys-date	Show the system date and time.	pal-show-sys-date	
pal-show-sys-gateway	Get the gateway of the switch and which port it is bound to.	pal-show-sys-gateway	
pal-show-sys-led	Show the FLEX port LED mode.	pal-show-sys-led	
pal-show-sys-log	Display a detailed system log.	pal-show-sys-log	
pal-show-sys-hostname	Show the hostname of the switch.	pal-show-sys-hostname	
pal-show-sys-ip	Show the IP addressing information from the switch.	pal-show-sys-ip	
pal-show-sys-temp	Show the temperature of the switch.	pal-show-sys-temp	
pal-show-sys-timezone	Display the current timezone of the switch.	pal-show-sys-timezone	
pal-show-vlan	Show VLAN port configuration.	pal-show-vlan	

Command	Purpose	Usage	Usage Notes
pal-show-vlan-default	Show the default VLAN's configuration.	pal-show-vlan-default {<1-24> all system}	<1-24> and all are port defaults, where system is the system default.
pal-show-voltage	Show the downlink voltage in Decivolts.	pal-show-voltage	
pal-version	Show the version of the software on the switch.	pal-version	

Upgrade Procedure

Use the command line interface in Admin > Terminal to upgrade, remove, and show the installed software packages on the switch (see page 31).

NOTE

Full packages will be released with every major software release; these packages will not require a certain previous version to be installed. Incremental upgrade packages will constitute non-critical but recommended upgrades. When applying incremental upgrades, all upgrades must be done in order and no upgrades can be skipped.

IMPORTANT

Exporting the switch configuration file is recommended before performing an upgrade. For details, see "Admin > Setup" on page 25.

Command	Purpose	Usage	Usage Notes
pal-pkg	Used to upgrade, remove, and show the installed software packages on the switch.	pal-pkg {show_remote show_installed install_all remove_all} pal-pkg install <REMOTE_PACKAGE_NAME> pal-pkg remove <LOCAL_PACKAGE_NAME> pal-pkg configure <URI VERSION>	<REMOTE_PACKAGE_NAME> is a single-value entry of the remote package name you wish to install, residing on your HTTP or FTP server. <LOCAL_PACKAGE_NAME> is a single-value entry of the local package name you wish to remove, residing on your switch. <URI VERSION> is a single-value entry of the URL of the files, residing on the server.

Notes:

- Commands must be entered exactly as shown in the Usage column.
- <> denote single-value entries of a specific item, as explained within the brackets.
- { } denote a set or list or range of entries for a specific item.

Displaying the current installed version

When performing an incremental upgrade, you will need to know the current installed version of firmware on the unit so the next upgrade can be installed. When applying incremental upgrades, all upgrades must be done in order and no upgrades can be skipped.

Example usage:

```
# pal-version
X.X.X
#
```

Incremental upgrade

1. On the server, create a directory (using any name) and place the upgrade file into the directory. Supported servers are HTTP and FTP.

Example usage:

```
http://192.168.0.10/upgrade/switch.X.X.X.bin
http://192.168.0.10/upgrade/sources
```

2. From the switch command line on the Admin > Terminal tab, configure the package upgrade utility to point it to the upgrade server and subfolder. This is done with the **pal-pkg** command with the configure option **pal-pkg configure <URL><SUBFOLDER>**. In the URL, you must specify the server type (FTP:// or HTTP://) and the IP address.

Example usage:

```
# pal-pkg configure http://192.168.0.10 upgrade
#
```

3. To verify the upgrade server and switch are now configured properly for upgrade, issue the **pal-pkgshow_remote** command (this will display the upgrade file on the server).

Example usage:

```
# pal-pkgshow_remote
switch.X.X.X.bin
#
```

4. Once the switch can access the server, use the **pal-pkg install all** command to perform the upgrade. You will be notified if a restart is required after installing and starting the upgrade. Upgrades in this fashion are done incrementally.

Example usage:

```
# pal-pkg install switch.X.X.X.bin
Installing UPGRADE .....[OK]
Starting UPGRADE .....[OK]
#
```

Upgrade recovery and full version install

It is recommended that all upgrades are done using the incremental method. In case of problems, the following instructions can be followed.

NOTE

Holding down the reset button during the bootup process will reset the unit to the default factory settings.

Example usage:

```
# pal-pkg show
switch.X.X.X.full.bin
# pal-pkg install switch.X.X.X.full.bin
Installing X.X.X.FULL .....[OK]
Starting X.X.X.FULL .....[OK]
Restart is needed
#
```

7. Troubleshooting

Most issues can be identified from the initial System > Overview page.

- Monitor the switch **Temperature** in the System Overview panel. To see temperature pattern and threshold, go to the Performance tab.
- The shading of the port number in the Ethernet Ports table indicates any network issues; see **Viewing port status** on page 6.
- If the port number is in red text and there is a high number in the **Sync** field, there are likely physical errors with the port and/or cable.
- To further investigate a high **Sync** number, double-click on the number to view link transition statistics for the port. This historical information can help you to identify patterns of downtime (e.g. frequency, consistent time, duration, etc.).
- Hover over a port number to see the number of packets received and transmitted. For a breakdown of these, go to the Ethernet > Downlink Ports page and hover over the **Total** number.