
SCP-100/110 Resetable Switch Call Point Installation Manual

※ Features

- 1. Reversionary design, obvious indicators around the edges of the unit.
- 2. Press the pressing plate to set the red indicator.
- 3. Pressing plate with status (green and red) shown.
- 4. Reversionary key with non-slip design.
- 5. Input power range from DC12-24V to connect with all types of fire alarm system.
- 6. Built-in buzzer status to set as silent, interval wailing or continuous wailing. Volume is adjustable.
- 7. Easy to assemble, outer case without screws, 3 set of output points to connect other equipment, embedded or surface installations to select. Note: SCP-100 only has output point function.

X Accessories




X Specifications

Model Item	SCP-110	SCP-100	Note
Power supply	DC 12V~DC 24V	×	± 5%
Operation current	DC 12V/18mA(Standby)/75mA(Operation)	X	± 5%
	DC 24V/11mA(Standby)/41mA(Operation)	×	± 5%
Buzzer	Set as silent, interval wailing or continuous wailing	×	-
Indicator	Dual-color (red and green) . Red indicator to set blinking , off or on.	×	
Output	N.O. N.C.& COM.Output (Maximum load of 125V/3A)		
Weight	SCP-100:192g / SCP-110:208g		
Dimensions	90mm(L)x93mm(W)x45mm(H)		
Material	ABS, PC(transparent part)		




Status display : Green




[Operation]

Status display: Red




※ Connections

※ Wiring Diagram




X Attention before installation



% Installation

Surface Installation



Embedded Installation

