Control Panel settings

- With the required connections made and mains power present, the internal communications card must be switched on by following the steps;

From access level 3, press the 3 Button until the screen displays:

```
→Panel Information
 Language Select
 Factory Access
 Reports
```

Press the ✓ button and the screen will display:

```
→Edit Users
 Panel Options
 System Options
 Communication
```

Press the 3 button until the screen displays:

```
 Edit Users
 Panel Options
 System Options
→Communication
```


Control Panel settings

Press the ✓ button and the screen will display:

```
→Read/Write USB
 Remote Access
```

Press the 3 button and the screen will display:

```
 Read/Write USB
→Remote Access
```

Press the ✓ button and the screen will display:

```
→Remote Access OFF

✓ Continue  Change >
```

Press the ✓ button and the screen will display:

```
 Using Remote Access
   May Incur Costs

< Cancel    Confirm >
```

Control Panel settings

Press the ✓ button and the screen will display:

```
For Access Enter
Activation Code:

Press ✓ To Complete
```

Enter the engineer PIN code *(default '333333')*, then press the ✓ button to confirm. The screen will display:

```
→Remote Access    ON


✓ Continue  Change >
```

Press the ✓ button and the screen will display:

```
→Internal Comms
 Account Settings
```

Press the ✓ button and the screen will display:

```
→View Status
 Edit Options
```


Control Panel settings

Press the 3 button and the screen will display:

```
 View Status
→Edit Options
```

Press the ✓ button and the screen will display:

```
→Module In Use    NO


 Press ✓ To Select
```

Press the ✓ button and the screen will display:

```
 Module In Use  ?
→NO
 YES
 Press ✓ To Select
```

Press the 3 button and the screen will display:

```
 Module In Use  ?
 NO
→YES
 Press ✓ To Select
```

Control Panel settings

Press the ✓ button and the screen will display:

```
 Module In Use    YES
 ARC Enable        NO
→Services         YES
 Press ✓ To Select ⇕
```

Press the 3 button to scroll through the list and press the ✓ button to change any options that are currently set as no, to yes. Applicable options are shown below:

```
→Module In Use   YES
 ARC Enable      YES
 Services        YES
 Remote Confis   YES
 IP Port Used    YES
 GPRS Used       YES
 Stats           YES⇕
```


Control Panel settings

Once complete, press the 4 button and the screen will display:

```
 View Status
→Edit Options
                ⇕
```

Press the 1 button and the screen will display:

```
→View Status
 Edit Options
                ⇕
```

Press the ✓ button and the screen will display:

```
→Module In Use  YES
 Module Status   OK
 ARC Enable     YES
 Services       YES⇕
```

Control Panel settings

Press the 3 button to scroll through the list to check the status of the 'IP Status' and the 'GPRS Status' are as required, prior to account creation.

```
→Module In Use   YES
 Module Status    OK
 ARC Enable      YES
 Services        YES
 Remote Config   YES
 IP Port Used    YES
 IP Status        OK
 GPRS Used       YES
 GPRS Status      OK
 GPRS Sig       GOOD
 Stats           YES
```

Once complete, press the 4 button and the screen will display:

```
→View Status
 Edit Options
```


Control Panel settings

Press the 4 button and the screen will display:

```
→Internal Comms
 Account Settings
```

Press the 3 button and the screen will display:

```
 Internal Comms
→Account Settings
```

Press the ✓ button and the screen will display:

```
→Create Account
 View Settings
 Edit Settings
```

Press the 3 button until the screen displays:

```
 Create Account
 View Settings
→Edit Settings
```

Control Panel settings

Press the ✓ button and the screen will display:

```
→IP Address -     IP
 IP Ports -       IP
 IP Address -   GPRS
 IP Ports -     GPRS
```

Press the 3 button until the screen displays:

```
 Panel IP Address
 Panel Type
→VAR Code
```

Press the ✓ button and the screen will display:

```
ABC

Edit ⇕     ✓ To Enter
```

Enter your three digit VAR code.

Note: your VAR code is available from your distributor.

Control Panel settings

Once complete, the screen will display:

```
 Panel IP Address
 Panel Type
→VAR Code
```

Press the 4 button and the screen display:

```
 Create Account
 View Settings
→Edit Settings
```

Press the 1 button until the screen displays:

```
→Create Account
 View Settings
 Edit Settings
```

Press the ✓ button and the screen will display:

```
Creating Account

VAR002222
```

Control Panel settings

Followed by confirmation of successful account creation. Note: this may take up to 10 minutes to complete.

```
Creating Account
Creation Succeeded
VAR002222
```

The newly created account will now be live and visible within SmartCell Services.