

Touch Screen Keypad Logo Editor



Designed and Manufactured in the United Kingdom


www.orisec.co.uk

The purpose of this document is to outline each step for uploading a professional logo into an Orisec Touch screen keypad.

To start the logo upload, you will require;

- ► A Windows based computer (Recommended spec Windows 7 onwards)
- ► A micro USB lead
- ► An Orisec TK-650 keypad
- ► .PNG image to upload (480x272 pixels)

With the device powered plug the Micro USB on as shown below;



Uploading an image

1. Open the Orisec 'RKP Logo Editor Program' – Default Icon;



2. With the Micro USB connected as illustrated above, from the drop-down box select the comport required followed by 'Connect'.



3. Product information for the keypad will be shown in the 'Product Information' field, once ready press the 'Next' button.



4. Select the logo to be uploaded by using the 'OPEN' button.

Once done a preview will be loaded onto the screen.



NOTE: If the image being uploaded is bigger than 480x272 pixels the program will resize the image to the required size, the following information box will populate the screen.



5. Once the image has been previewed press the 'NEXT' button.



6. Select an icon from any of the 13 pre-sets or upload a personalised icon image, once selected press the 'NEXT' button.



NOTE: If uploading a personal icon this should be 32x32 pixels and PNG format.

7. To Start the Logo upload, press the 'Start' button, the logo will now be uploaded to the touch screen keypad.



NOTE: During the Logo upload do not disconnect the USB lead.

8. Once the Logo is uploaded, the Micro USB lead can be removed and the program closed.

NOTE: Ensure 'Show Logo Screen' is enabled on the Orisec Touch Screen keypad to view the image please refer to Orisec TK-650 Touch Keypad Installation Manual (INS026) manual for additional information.

Notes

Notes

www.orisec.co.uk

UK Based Technical Support

t: +44 (0) 1706 398740 e: support@orisec.co.uk

© Orisec Ltd 2018

INS066