

# Snel inschakelen via een NXG-1830

Ontdek hoe men snel (zonder code ingave) kan inschakelen via een NXG-1830 keypad.

- 1) Activeer de optie “snel inschakelen” in de menu Partities.

The screenshot shows the configuration interface for the NXG-1830 keypad. At the top, there are tabs for 'Send', 'Read', 'Options', and 'Display'. Below these is a navigation bar with a search icon, a list icon, and a page indicator showing '1 of 8'. The main content area has three tabs: 'Partition Options' (highlighted with a red box), 'Partition Type And Timers', and 'Partition Event Reporting'. Under 'Partition Options', there is a 'Partition Number' dropdown set to '1' and a 'Partition Name' text field containing 'Woning'. Below these are two sections of options. The first section, titled 'Options', contains a list of checkboxes: 'Arm-Disarm Reports' (checked), 'Quick Arm' (checked and highlighted with a red box), 'Arm In Stay If No Exit' (unchecked), 'Quick Stay Mode Disarm' (unchecked), 'Siren Chirp Away' (unchecked), 'Siren Chirp Stay' (unchecked), 'Force Arm With Bypass' (unchecked), 'Force Arm Without Bypass' (unchecked), 'Silent exit' (unchecked), 'Manual Fire' (checked), 'Manual Auxiliary' (checked), 'Manual Panic' (checked), 'Use Partition 1 Options' (unchecked), 'Bypass Requires PIN' (unchecked), 'Manual Panic is Silent' (checked), and 'Arm In instant If No Exit' (unchecked). The second section, also titled 'Options', contains a single checkbox 'LED Extinguish NX Keypad' which is unchecked.

- 2) De-activeer de onderstaande opties bij de klavier instellingen
  - a. Pin code nodig voor ontgrendelen van de screensaver (idle PIN)
  - b. Screen Saver
  - c. Geef logo weer

2 NXG1830 - 0102

Send Read Options Display

Keypad Button Functions

Name: NXG-1830

Permission 1: 125 All Partitions

Schedule 1: Always On

Permission 2: 125 All Partitions

Schedule 2: Always On

Language: English (U.K.)

Options

☒ Tamper

☐ Idle PIN

☐ Silent

☒ Clock 24h

☐ Screen Saver

☐ Show Logo

☒ Show Clock

LCD Brightness [0-10]: 6

LCD Idle Brightness [0-10]: 1

LCD Contrast [0-10]: 5

KP Brightness [0-10]: 6

KP Idle Brightness [0-10]: 1

LCD Color: White

KP Color: Same as LCD

Tone [0-10]: 4

Volume [0-10]: 10

Alarm Vol [0-10]: 10

EE Vol [0-10]: 10

Idle Time [10-240]: 30