




Module	Dip Switch	Description
Power Supply	PS/SW1-SW3	Used to set a unique ID number for the Bus module for communication purposes.
	PS/SW4	Enables/Disables Power Supply - ProSYS communication. On (up): Communication enabled. Off (down): Communication disabled
Utility output	UO/ SW1-SW3	Used to set a unique Bus ID number for the UO module located on the SMPS board.
	UO/SW4	Enables/disables UO module - ProSYS communication. On (up): communication enabled. Off (down): communication disabled

UO adres1:relay1=out5
relay 2=out6

UO adres2:relay1=out7
relay 2=out 8

UO adres3:relay1=out9
relay 2=out 10