AxTraxNG Quick Guide August 2012



Upgrading from VeriTrax to AxTraxNG

To upgrade from VeriTrax to AxTraxNG:

- 1. If your version of VeriTrax uses a MS Access database, skip to Step 6.
- 2. Back up the database:
 - a. Click **Tools>Database**.
 - b. In the Select database options dropdown, select Export Configuration and Events.

xport Configurations and Events t	to computer's 'sofia' local directories
xport Configurations and Events t	0
	Proves
	biowse
nte: The selected file name will be	e annended with Veritray v7
ster The selected his hame will be	c appointed with _volida_vi

- c. Browse to the location on your computer to save the file and click Save.
- d. Click **OK**.

The database file is saved with the following naming convention: xxxx_Veritrax5_Veritrax_vxx.bak

- 3. Uninstall the VeriTrax application.
- 4. Install AxTrax v4.25 using actual Authentication user name and password (database password for user sa: 9590693).
- 5. Import the database file from Step 1 to AxTrax v4.25:
 - a. Click Tools>Database.
 - b. In the Select database options dropdown, select Import earlier database version from Veritrax AS-225/AxTrax AS-525.

Database	×
Calast database estima	
import earlier database versions from veritrax AS-225/AXTrax AS-525	
- Investigation details and unseigned (new) (without AC, 205 (AuTrau, AC, 525 -	
MS SQL Server Veritrax v bak File from Veritrax AS-225/AxTrax AS-325	S-525
	Browse
_	
01/	Gunnal
UK	Lancel

- c. Browse to the root folder (C:\) and select the database file.
- d. Click **OK**.
- e. Skip to Step 7.



Upgrading from VeriTrax to AxTraxNG

 Import the MS Access database with file name AC215Database.mdb, located at the following path: c:\Program Files\Rosslare\Veritrax

Database		×
Select database options		
Import earlier database versions from Veritra	(AS-215	•
 Import earlier database versions from Veritra MS Access Data Base from Veritrax AS-215 	ax AS-215 5 0.5-2.02.04, 2.05.00-2.0	15.06
E:\Applic\AC215\Veritrax 2.05.07\Veritrax	2.05.07_AC215DataBas	e.mdb
		Browse
	ок	Cancel

- 7. Back up the database:
 - a. Click Tools>Database.
 - b. In the Select database options dropdown, select Backup Now.

atabase		X
Select database options		
Backup Now	_	
Backup Now Backup folder C:\Program Files\rosslare\AxTrax AS-525\Backup\Veritrax5.bak		
	Browse	
Note: The selected file name will be appended with _Veritrax_v23		
OK	Cancel	

- c. Keep the default folder location.
- d. Click OK.

The database file is saved with the following naming convention: xxxx_Veritrax5_Veritrax_v23.bak

- 8. Copy the file to the root directory (C:\)
- 9. Uninstall AxTrax v4.25.
- 10. Install the AxTraxNG software.
- 11. Import the database file from Step 6 to AxTraxNG:
 - a. Click Tools>Database.
 - b. In the Select database options dropdown, select Import earlier database version from Veritrax AS-225/AxTrax AS-525.



Upgrading from VeriTrax to AxTraxNG



- c. Browse to the root folder (C:\) and select the database file.
- d. Click **OK**.

The application closes while the database is imported.



