

# Configuration software ASD Config

V: 2.5.0

Product change request: ----/--

## Software identification:

| Filename                             | Software version |        | Released   | Dependency ASD FW    |
|--------------------------------------|------------------|--------|------------|----------------------|
|                                      | New              | Basis  |            |                      |
| ASD Config 2.5.0 Setup Securiton.exe | 2.5.0            | 2.2.10 | 28.02.2023 | see "Compatibility:" |
| ASD Config 2.5.0 Setup Hekatron.exe  |                  |        |            |                      |
| ASD Config 2.5.0 Setup Schrack.exe   |                  |        |            |                      |

## Changes V: 2.5.0:

| CR    | Type | Description  |
|-------|------|--|
| 2.4.0 | N    | <ul style="list-style-type: none"><li>• New additional modules UIM, ML-SFD, LIM.</li><li>• Various text corrections.</li><li>• System update and bug fixes for securing system stability.</li></ul>  |
| 2.5.0 | N    | <ul style="list-style-type: none"><li>• Extended airflow limits (setting range via ASD Config +/- 99%, only with manufacturer dongle)</li><li>• REK application (only for ASD 535-1 / and ASD 535-3)</li><li>• Readout of production data from AMB and SSD</li><li>• Import of old project files in ASD Config</li><li>• System update and bug fixes for securing system stability</li></ul> |

## Obligation to replace:

For all new ASD applications, only configuration software 2.5.0 is to be used.

## Compatibility:

Compatible as of ASD FW V: 01.04.08 resp. 01.10.05.



### Installation notice

- The ASD Config configuration software can be run with Windows 7 SP1 (32 & 64 bit), Windows 8.1 (64 bit) and Windows 10 (64 bit, at least V1809).
- **Note Windows 7:** For the installation of the framework 4.8 with Windows 7 the update package KB2813430 is necessary (note the x64/x86 version)
- Minimum system requirements: 200 MB free hard disk space; 1 GB RAM; CPU = 2 GHz (single) / 1.5 GHz (dual); GPU = DirectX 9 capable.
- Screen resolution: at least 1280 x 720 pixel.
- 1 available Ethernet or USB connection and 1 available USB connection for the ULM dongle.
- The corresponding .NET language pack may have to be installed to display the texts correctly in the program.
- Program to display PDF reports (e.g. Adobe Reader). The "Arial Unicode MS" or "Arial Unicode MS Standard" font must be present for Asian symbols to be printed (e.g. installed with MS Office).
- Internet Explorer 11 or Microsoft Edge (Online Help).

If a previous version of ASD Config is installed on the PC, it must be uninstalled prior to the new installation. This is performed via the Control Panel of the PC via "Remove program".

### Notes for the IT administrator:

By entering the following command in the command line, the software can be silently installed or uninstalled:

- Installation: `"Path\Setup.exe" -q`
- Deinstallation: `"Path\Setup.exe" -uninstall -q`

### Remarks:

- The entry between the quotation marks corresponds to the path where the setup file is stored and the file name specified on page 1 (software identification).
- The installation path can be specified with `InstallFolder="C:\AnyPath"` (attention: case sensitive). Without this specification the default path is used.